

Quick Installation Guide

Wireless Share Router

iShare2




Package contents

iShare2 x 1 Ethernet Cable x 1

Quick Installation Guide x 1 Flannelette Bag x 1

Note: If any of items is missing or damaged, please contact your retailer.

Hardware




| No. | Interface | Description |
|-----|------------------|--|
| 1 | Mode Switch | AP/Repeater/Router |
| 2 | System Indicator | Solid Red: System booting Solid blue: power ON and works well Blue flash: WPS processing or configuration on App comes into effect |
| 3 | USB | USB drive connection or 5V/1A adapter |
| 4 | RST | Long-press for 3-5S to restore factory defaults |
| 5 | LAN/WAN | 10/100Mbps Ethernet port |
| 6 | WPS | Used to secure your wireless network automatically |

Working Mode

AP Mode (Access Point)


In AP mode, iShare2 creates your own WiFi hotspot by connecting to a wired Internet connection.



Recommend for: hotel, small office, etc.

Repeater Mode (Wireless Repeater)


In Repeater mode, iShare2 extends the coverage of your existing wireless router.



Recommend for: villa, big house, etc.

Router Mode (Wireless Router)

In Router mode, iShare2 works as a wireless router.



Recommend for: home, apartment, etc.

Network Configuration

AP Mode Setup

Please check the mode switch on the iShare2 is set to AP mode.

1. Plug the iShare2 into an electrical outlet, use an Ethernet cable to connect the iShare2 to the router Ethernet LAN port or the remote Ethernet LAN jack, and wait the system indicator turn from red into blue.
2. On your computer/ Smart phone /tablet, find and join iShare2's WiFi network to access Internet. The default wireless network name is **AirMobi_XXXXXX** and password is **0123456789**.




Repeater Mode Setup

Please check the mode switch on the iShare2 is set to Repeater mode.

Option A: Setup with WPS (Wi-Fi Protected Setup)

Press the WPS button on your existing wireless router, within two minutes, press the WPS button on iShare2, iShare2 will be connected to your existing wireless router automatically.



When the connection is complete, the iShare2 will use the same wireless network name (SSID) and password as your existing wireless router.

Option B: Setup with web UI setup

1. Follow the step 1, 2, 3 in **Router Mode Setup**.
2. Log in to setup wizard page, follow **Setup Wizard** to complete setup.



3. Click **Next** button into internet connection configuration in Repeater mode.

| Configuration Repeater | |
|------------------------------------|---|
| Access wireless network name(SSID) | <input type="text" value="AirMobi FB77DF"/> <input type="button" value="Search"/> |
| | <input checked="" type="checkbox"/> Synchronism SSID |
| Security Mode | WPA2-Personal ▾ |
| Encryption Type | AES ▾ |
| Pass Phrase | <input type="text"/> |

Click **Search** button to select a wireless network to extend, and type the network password.



When the connection is complete, the default setting is **Synchronism SSID**.

The iShare2 will use the same wireless network name (SSID) and password as your existing wireless router.

If the **Synchronism SSID** not checked, click the **Next** button into configure your WiFi security, enter the WiFi name and password for iShare2's wireless network.

| Configure your Wi-Fi security | |
|--|---|
| Wireless network name(SSID) | <input type="text" value="AirMobi FC4A71"/> |
| Wireless Security Options | |
| <input type="radio"/> Disable wireless security | |
| <input checked="" type="radio"/> Enable wireless security | |
| <input type="text"/> (8-63 ASCII characters or hexadecimal characters) | |

4. Click the **Next** button, complete the network configuration in Repeater mode. Connect your computer/Smart phone/tablet to the new created wireless network.


Router Mode Setup

Please check the mode switch on the iShare2 is set to Router mode.

1. Plug the iShare2 into an electrical outlet, check the device connection follow the diagram in Working Mode, and wait the system indicator turn from red into blue.
2. On your computer/ Smart phone /tablet, find and join iShare2's WiFi network. The default wireless network name is **AirMobi_XXXXXX** and password is **0123456789**.



3. Open a web browser and enter “192.168.8.8” in the address bar, enter the username and password, the default setting is **admin/admin**.



4. Log in to setup wizard page, follow **Setup Wizard** to complete setup.




5. Click **Next** button into Internet connection configuration in Router mode.
In Router mode, there are three Internet connections available: **Static IP**, **DHCP**, and **PPPoE**.

Select the right Internet connection, the configuration data can be get from your ISP.


PPPoE: Used for ADSL services, type in the **username** and **password** provided by your ISP.

| | |
|---|--------------------------|
| This router supports three types of network connection modes. Please select an appropriate one according to the actual situation. | PPPoE ▼ |
| PPPoE Mode | |
| Username | <input type="text"/> |
| Password | <input type="password"/> |
| Verify Password | <input type="password"/> |

DHCP: Nothing provided by Your ISP, without doing any configurations.

| | | |
|---|--|--|
| This router supports three types of network connection modes. Please select an appropriate one according to the actual situation. | DHCP  | |
| | DHCP Mode | |
| Host Name | <input type="text"/> | |

Static IP: Type in the **Static IP Address, Subnet Mask, Default Gateway and DNS Server Address** provided by your ISP.

| | | |
|---|--|--|
| This router supports three types of network connection modes. Please select an appropriate one according to the actual situation. | Static IP  | |
| | Static IP | |
| IP Address | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> | |
| Subnet Mask | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> | |
| Default Gateway | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> | |
| Primary DNS Server | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> | |
| Secondary DNS Server | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> (Optional) | |

6. Click the **Next** button into configure your WiFi security, enter the WiFi name and password for iShare2's wireless network.

| | |
|--|---|
| Configure your Wi-Fi security | |
| Wireless network name(SSID) | <input type="text" value="AirMobi FC4A71"/> |
| Wireless Security Options | |
| <input type="radio"/> Disable wireless security | |
| <input checked="" type="radio"/> Enable wireless security | |
| <input type="text"/> (8-63 ASCII characters or hexadecimal characters) | |

7. Click the **Next** button, complete the network configuration in Router mode. Connect your computer/Smart phone/tablet to the new created wireless network.

AirMobi Application

App installation

For iOS devices:

Search **AirMobi** in App Store, or scan the QR code, download and install the Apps.

For Android devices :

Search **AirMobi** in Google Play store , or scan the QR code, download and install the Apps.




After completed installation, click the icon

application.





to open the **AirMobi**



Network configuration through AirMobi App

1. On your computer/Smart phone /tablet, find and join iShare2's WiFi network. The default wireless network name is AirMobi_XXXXXX, and password is 0123456789.
2. Open AirMobi App, click **Setting** to login page.
Type the default password **admin**.
3. Log into Setup Wizard page, follow **Setup Wizard** to complete setup.



4. After configuration completed, Connect your computer/Smart phone/ tablet to the new created wireless network.

Wireless Data Share



1. Plug the iShare2 into an electrical outlet, insert USB disk/hard disk into USB port, and wait the system indicator turn from red into blue.
2. On your computer/ Smart phone /tablet, find and join iShare2's WiFi network.

For Android/iOS mobile devices

You can use AirMobi App to view and download the music, videos, photos and documents from USB disk/hard disk.

In **Files manager** page, you can delete or download the files from USB disk/hard disk.

In **Backup** page, you can upload files in mobile devices to USB disk/hard disk.



For Windows/Mac OS computer

Open “my computer” or “computer”, enter “\\192.168.8.8” in the address bar , and enter the username and password, the default setting is **admin/admin**, you can access all files from USB disk/hard disk, and upload files in computer to USB disk/hard disk.



For DLNA devices

For computer, Smart TV compatible with DLNA standards, you can access the videos, musics, photos from USB disk/hard disk.

Technical Support

For more information or troubleshooting help, please download the User Manual from our website.

Additional support is also available on our website: **www.cctairmobi.com**

The website contains the latest user documentations and software updates for AirMobi products.

Support E-mail Address: support@cctairmobi.com

Copyright©2013 Shenzhen Huaxunark Technology Co., Ltd. All rights reserved.

A decorative wavy line composed of several overlapping, semi-transparent gray shapes, creating a modern, abstract look at the bottom of the page.